

- 1 - WOODEN HANDLES X 3pcs
- 2 - STAINLESS STEEL SKEWER STICKS X 3pcs
- 3 - IRON STRIPE X 2pcs
- 4 - BOLT NUTS X 4pcs
- 5 - IRON T-STANT X 1pcs
- 6 - SKEWER GEAR X 1pcs
- 7 - WOODEN HANDLE LEVELING X 1pcs
- 8 - WOODEN HANDLE CLAMP X 1pcs
- 9 - IRON LEGS X 4pcs
- 10 - MAIN BODY (FIRE PLACE) X 1pcs
- 11 - KEBAB GEAR X 1pcs
- 12 - KEBAB STAINLESS STEEL STICKS X 11pcs
- 13 - BUTTERFLY SCREW X 4pcs
- 14 - MOTOR

ASSEMBLAGE STEPS

First correctly orient the Main Body (FIRE PLACE) in front of you (see assemblage map on the left)

Step A: Attach the wooden handles to the stainless steel skewer sticks using a hammer.

Step B: Attach the iron legs to the main body (Fire Place) using butterfly screws, which are already attached to the legs.

Step C: Place the iron T-stand on the left side of the main body (Fire Place) and adjust it vertically using bolt nuts.


Step D: Place the skewer gear on the right side of the main body (Fire Place). Then, place and adjust the iron strip vertically and secure it with one bolt nut. Then, place the wooden handle for leveling and secure the bottom of the vertical iron strip using the bolt nut. Finally, use the wooden handle clamp to lock the system at a comfortable level.

Step E: Attach the kebab gear to the hooks located at the back side of the main body (Fire Place).

Use only D/C motors for rotating the gears and to place the kebab sticks or skewer sticks carefully onto the gears.



FOUKOUES.COM



- 1 - WOODEN HANDLES X 3pcs
- 2 - STAINLESS STEEL SKEWER STICKS X 3pcs
- 3 - IRON STRIPE X 2pcs
- 4 - BOLT NUTS X 4pcs
- 5 - IRON T-STANT X 1pcs
- 6 - SKEWER GEAR X 1pcs
- 7 - WOODEN HANDLE LEVELING X 1pcs
- 8 - WOODEN HANDLE CLAMP X 1pcs
- 9 - IRON LEGS X 4pcs
- 10 - MAIN BODY (FIRE PLACE) X 1pcs
- 11 - KEBAB GEAR X 1pcs
- 12 - KEBAB STAINLESS STEEL STICKS X 11pcs
- 13 - BUTTERFLY SCREW X 4pcs
- 14 - MOTOR

ASSEMBLAGE STEPS

First correctly orient the Main Body (FIRE PLACE) in front of you (see assemblage map on the left)

Step A: Attach the wooden handles to the stainless steel skewer sticks using a hammer.

Step B: Attach the iron legs to the main body (Fire Place) using butterfly screws, which are already attached to the legs.

Step C: Place the iron T-stand on the left side of the main body (Fire Place) and adjust it vertically using bolt nuts.

Step D: Place the skewer gear on the right side of the main body (Fire Place). Then, place and adjust the iron strip vertically and secure it with one bolt nut. Then, place the wooden handle for leveling and secure the bottom of the vertical iron strip using the bolt nut. Finally, use the wooden handle clamp to lock the system at a comfortable level.

Step E: Attach the kebab gear to the hooks located at the back side of the main body (Fire Place).

Use only D/C motors for rotating the gears and to place the kebab sticks or skewer sticks carefully onto the gears.



Dear Customer,

Assemblage of the barbeque Foukou units diagram is shown on the inside page of this flyer.

Please read and take note of the following comments regarding your protection and safety against risk of injury and fire.


- Lighting of fire should always take place outdoors.
- Always check that there are no electric cable or flammable items near the area of lighting the fire.
- Lighting of charcoal should always be done according to instructions of the supplier.
- After each use remove any charcoal remains carefully and store the main body (fire place) and its accessories units in a safe place away from children.
- The barbeque and all its accessories must be kept in a dry place.
- Take care while using the sharpened sticks.
- When using the fire place make sure that you do not touch the iron parts because these are extremely hot.
- Always use a D/C Motor. Never use an A/C Motor.
- The supplier of the barbeque units is not responsible for improper use of the fire place or its accessories



**Agias Theklis 21,
Limassol 3042**



Telephone: +357 99 790 103
Email: barbequecy00@gmail.com
Website: foukoues.com



- 1 - WOODEN HANDLES X 3pcs
- 2 - STAINLESS STEEL SKEWER STICKS X 3pcs
- 3 - IRON STRIPE X 2pcs
- 4 - BOLT NUTS X 4pcs
- 5 - IRON T-STANT X 1pcs
- 6 - SKEWER GEAR X 1pcs
- 7 - WOODEN HANDLE LEVELING X 1pcs
- 8 - WOODEN HANDLE CLAMP X 1pcs
- 9 - IRON LEGS X 4pcs
- 10 - MAIN BODY (FIRE PLACE) X 1pcs
- 11 - KEBAB GEAR X 1pcs
- 12 - KEBAB STAINLESS STEEL STICKS X 11pcs
- 13 - BUTTERFLY SCREW X 4pcs
- 14 - MOTOR

ASSEMBLAGE STEPS

First correctly orient the Main Body (FIRE PLACE) in front of you (see assemblage map on the left)

Step A: Attach the wooden handles to the stainless steel skewer sticks using a hammer.

Step B: Attach the iron legs to the main body (Fire Place) using butterfly screws, which are already attached to the legs.

Step C: Place the iron T-stand on the left side of the main body (Fire Place) and adjust it vertically using bolt nuts.

Step D: Place the skewer gear on the right side of the main body (Fire Place). Then, place and adjust the iron strip vertically and secure it with one bolt nut. Then, place the wooden handle for leveling and secure the bottom of the vertical iron strip using the bolt nut. Finally, use the wooden handle clamp to lock the system at a comfortable level.

Step E: Attach the kebab gear to the hooks located at the back side of the main body (Fire Place).

Use only D/C motors for rotating the gears and to place the kebab sticks or skewer sticks carefully onto the gears.